

Setting up your Wood Burning Oven



Site your oven on four 24"x24"x2" slabs and seal the gap with silicon sealer ensure that the slabs slope down from the center to the outside edge.



Put about 50 kg of dry sharp sand or building sand on the top of the slabs and spread it out.



Level the sand so that the back of the oven has 2" of sand under it while the front has a half inch of sand the oven should slope upwards from front to back.



place a sturdy piece of timber across the middle of the oven or use sturdy broom handle works well



4 people should lift the oven into place the piece of timber will help prevent the fingers from getting trapped



Now roll the oven back on the timber until the back lines up .



lift the front of the oven up remove the wood and lower into position



Oven in position



after the oven has been used a couple of times and has bedded down mix some normal sand and cement and fill the edge between the base and slabs



once the mix has started to set rub or scrap the excess off to get a neat finish .



When this has set the whole oven can be painted with your choice of cupernol wall or timber shades paint this will keep the oven dry and assist in performance